

Continental TSB 2024-1129A

Latest Technology REDI-Sensor™ TPMS Sensors Require TPMS Tool Update and New Sensor Configuration Process

- An up-to-date compatible TPMS tool is required to configure the proper communication protocol.
- Even brand-new tools may have outdated software; and some current TPMS Tools do not support our latest technology.

Four New REDI-Sensor™ Part Numbers Include



▪ SE10008

▪ SE10006

▪ SE10007

▪ SE10005

Step 1 | Confirm TPMS Tool Compatibility using list below

- | | | |
|------------------------------|----------------------|---------------------|
| ▪ Continental Autodiagnos D | ▪ BARTEC Tech300PRO | ▪ SNAP-ON TPMS5 |
| ▪ Continental Autodiagnos SE | ▪ BARTEC Tech400PRO | ▪ SNAP-ON TPMS4 |
| ▪ ATEQ VT67 | ▪ BARTEC Tech450PRO | ▪ MATCO MAXTPMS 2.0 |
| ▪ ATEQ VT57 | ▪ BARTEC Tech500PRO | ▪ MATCO MD56 |
| ▪ ATEQ VT56 | ▪ BARTEC Tech550PRO | ▪ MATCO MAXTPMS 3.0 |
| ▪ ATEQ VT47 | ▪ BARTEC Tech600PRO | ▪ COSTCO VT56 |
| ▪ ATEQ VT46 | ▪ BARTEC TechRitePRO | ▪ DILL D48 |
| ▪ ATEQ VT41 | ▪ SCHRADER S56 | ▪ OTC 3838 |
| ▪ ATEQ VT37 | ▪ TOPDON TP-47 | ▪ NAPA 92-1541 |
| ▪ HUF DT56 | ▪ SCHRADER S57 | ▪ NAPA 92-1551 |

Step 2 | Verify TPMS Tool has latest manufacturer software update

www.redi-sensor.com/updates or call our Tech Support at 800-265-1818 for assistance.

Step 3 | Follow new TPMS sensor configuration process

For new sensor configuration process instructions see next page or visit:

www.redi-sensor.com/updates or call our Tech Support at 800-265-1818 for assistance.



How to Videos

Public

Latest Technology REDI-Sensor™ TPMS Sensor Configuration Process

<p><u>Autodiagnos TPMS D and SE Tool</u></p> <p><i>For REDI-Sensor SE10005, SE10006</i></p> <p>Includes customized software to relearn REDI-Sensors in one step</p>	<p><u>Autodiagnos TPMS D and SE Tool</u></p> <p><i>For REDI-Sensor SE10007, SE10008</i></p> <p>Includes customized software to relearn REDI-Sensors in one step</p>
<p><u>ATEQ VT56, VT37, VT41, VT46, VT47 or equivalent</u></p> <p><i>For REDI-Sensor SE10005, SE10006</i></p> <p>ATEQ Relearn</p> <ol style="list-style-type: none"> Select Service or Service TPMS Select Make/Model/Year or VIN scan Select Relearn Trigger sensors following Relearn procedure <p><i>For REDI-Sensor SE10007, SE10008</i></p> <p>ATEQ Configure Sensor</p> <ol style="list-style-type: none"> Select Program Select Sensor Select REDI-Sensor Select Make/Model/Year <ol style="list-style-type: none"> Select Trigger to unlock protocol Repeat 'a' for each new REDI-sensor Return to Main menu, proceed to Relearn <p>ATEQ Relearn</p> <ol style="list-style-type: none"> Select Service Select Make/Model/Year or VIN scan Select Relearn Trigger sensors following Relearn procedure 	<p><u>Bartec Tech300Pro/Pro C, Tech400Pro, Tech500Pro, Tech450Pro, Tech550Pro, Tech600Pro and TechRitePro</u></p> <p><i>For REDI-Sensor SE10005, SE10006</i></p> <p>Bartec Relearn</p> <ol style="list-style-type: none"> Select New TPMS Service Select Make/Model/Year or VINdicat Relearn: OBD, Stationary, or Drive Trigger sensors following Relearn procedure <p><i>For REDI-Sensor SE10007, SE10008</i></p> <p>Bartec Relearn</p> <ol style="list-style-type: none"> New TPMS Service Make/Model/Year or VINdicat Program Sensors Menu <ol style="list-style-type: none"> REDI-Sensor to Unlock protocol Repeat for each sensor as needed Return to previous menu Relearn: OBD, Stationary, or Drive Trigger sensors following Relearn procedure
<p><u>Snap-On TPMS4</u></p> <p><i>For REDI-Sensor SE10005, SE10006</i></p> <p>Relearn</p> <ol style="list-style-type: none"> Select Relearn Select Make/Model/Year Select Trigger sensors following Relearn procedure <p><i>For REDI-Sensor SE10007, SE10008</i></p> <p>Configure Sensor</p> <ol style="list-style-type: none"> Select Special Functions Select REDI-Sensor Unlock Select Make/Model/Year <ol style="list-style-type: none"> Trigger to Unlock protocol Repeat for each sensor as needed. Return to previous menu <p>Relearn</p> <ol style="list-style-type: none"> Select Relearn Select Make/Model/Year Trigger sensors following Relearn procedure 	<p><u>Snap-On TPMS5</u></p> <p><i>For REDI-Sensor SE10005, SE10006</i></p> <p>Relearn</p> <ol style="list-style-type: none"> Select TPMS Select Make/Model/Year Select Relearn Trigger sensors following Relearn procedure <p><i>For REDI-Sensor SE10007, SE10008</i></p> <p>Relearn</p> <ol style="list-style-type: none"> Select TPMS Select Make/Model/Year Select Replace Select REDI-Sensor <ol style="list-style-type: none"> Trigger to Unlock Protocol Repeat for each sensor as needed Select Relearn Trigger sensors following Relearn procedure

Public